


## STEP 1

### Connect Converter



Plug VSU-485G into USB port



## STEP 2

### Install USB Driver for Windows®

Your computer system will ask you for the device driver location. Please point to the location of the driver file on the CD-Rom or download the driver from [www.virtualscada.com](http://www.virtualscada.com). Your computer system will update the driver list and install the USB converter automatically. A new virtual com port will now be available on your PC.

To check if the USB driver is installed successfully, please follow these steps:

- Go to your computer's Control Panel
- Click on System
- Click on Hardware
- Click on Device Manager
- Click on Ports (COM & LPT)
- Next unplug the USB device you just installed. If one of the communication port(s) disappears under the Port (COM & LPT), then the driver has been installed successfully.


**Make sure to note which communication port is used by the USB converter. Select this communication port in the communication setup window when using the iQpump® SCADA software.**

## STEP 3

### Connect iQpump® to Converter



Set switches to 'Off' and RS485



Visit us at [www.virtualscada.com](http://www.virtualscada.com)

iQpump® User Terminals

